

ASSEMBLY INSTRUCTIONS TRACK CLAW MODELS

STEP 1: CLEAN THE TRACK PAD AND REMOVE EXISTING DIRT



STEP 2: PUT THE SMALL PART ONTO THE TRACK PAD



STEP 3: PUT THE BIGGER PART ONTO THE PAD AND FIX IT WITH THE SMALL PART, USING THE SCREWS



STEP 4: TIGHT THE SCREWS AND CHECK THEM AFTER 1 HOUR FOR GOOD FITTING *



* TORQUE: M12 SCREWS: 130 NM - M16 SCREWS: 330 NM
DAILY CHECK OF GOOD FITTING BEFORE STARTING TO
OPERATE

Hettec Components GmbH, Schieddorf 24, A-5611 Großarl, Land Salzburg - AUSTRIA
Tel: +43 6414 8182, Mail: office@hettec.com, Web: www.hettec.com

